



Step 1: Remove plug from foot, knob, or accessory if one is present.



Step 2: Insert key into lock cylinder. All the locking tabs will retract, leaving only the wider retainer tab sticking out.



Step 3: Line up the wide retainer tab between the corresponding notches at the 10 o'clock position in foot, knob, or accessory.



Step 4: Turn key counter-clockwise to the 9 o'clock position and push lock into place.



Step 5: Turn key clockwise to the 12 o'clock position to lock foot, knob, or accessory.



Step 6: Remove key.